



La MARCHÉ®

OPTION "04G" 0/24 HR. AND OPTION "04H" 0/72 HR.

MANUAL EQUALIZE TIMERS

Equalize timers are used to raise the rectifier voltage to 2.33 Vpc (LA) or 1.55 Vpc (N.C.) so the battery can be given a high rate or equalize charge.

To operate the timer turn the timer knob to the approximate number of hours you wish the batteries to charge at equalize rate, then push the "start equalize" button.

The timer will time out and automatically returns the unit to the float position approximately 2.17 Vpc (LA) or 1.4 Vpc (N.C.).

To manually return the unit to the float rate, turn the timer knob counterclockwise to the detent position.

NOTE: THE ABOVE VALUES ARE THE STANDARD FACTORY SETTINGS.

ECN/DATE

106 BRADROCK DRIVE
DES PLAINES, IL. 60018
(847)299-1188
FAX: (847)299-3061

ISSUE DATE: 12036 - 6/98

INSTRUCTION DRAWING NUMBER:

P25-**LOPT04G/04H-1**