



# **La MARCHÉ**®

## **FORCE LOAD SHARING**

### **OPTION 10G**

Comprised of the following:

A load sharing switch located on the front of each unit and a terminal marked "1W" within each unit.

**NOTE: WHEN USING THIS OPTION, THE MODEL NUMBERS OF EACH UNIT SHOULD BE THE SAME.**

#### **OPERATION:**

1. Turn on one (1) rectifier and set the float and equalize voltage to the desired output.  
**DO NOT CONNECT BATTERY OR LOADS.**
2. Turn off first charger and set remaining chargers to the desired voltage, one at a time.
3. Turn off all chargers. Connect the "1W" terminal between all units and turn on load share switches.
4. Once properly set and connected, the rectifiers should share the load equally and charge the battery.

***(REFER TO SCHEMATIC FOR MORE INFORMATION)***

ECN/DATE


**106 BRADROCK DRIVE  
DES PLAINES, IL. 60018-1967  
(847) 299-1188  
FAX: (847) 299-3061**

ISSUE DATE: 14680 – 3/01

INSTRUCTION DRAWING NUMBER:

P25-**LOPT10G-1**