



La MARCHÉ®

PPC PowerPlus

Battery Charger /Battery Eliminator /Power Supply

ECN/DATE

CPN39698

	15349-06-6/02	14172 - 9/00	11801 - 4/98
	14575 - 2/01	13608 - 1/00	12670 - 1/99

106 BRADROCK DRIVE
DES PLAINES, IL. 60018
(847)299-1188
FAX: (847)299-3061

ISSUE DATE: 11615 - 3/98

INSTRUCTION DRAWING NUMBER:

P25-LPPC-1

INSTALLATION & OPERATING INSTRUCTIONS FOR PPC POWERPLUS

**IMPORTANT SAFETY INSTRUCTIONS
FOR THE
LA MARCHE POWER CONVERSION EQUIPMENT
SAVE THESE INSTRUCTIONS**

This manual contains important safety and operating instructions for the La Marche Power Conversion Equipment.

Before using this equipment, read all instructions and cautionary markings on (1) unit, (2) battery, and (3) product using the battery.

CAUTION: To reduce risk of injury and/or damage to the batteries, use only the type of batteries specified on the charger.

Do not expose equipment to rain or snow.

Do not operate equipment if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified serviceman.

Do not disassemble this unit; take it to a qualified serviceman when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.

To reduce risk of electric shock, disconnect this unit from the a.c. supply, or batteries and loads before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.

WARNING – THERE IS A RISK OF EXPLOSIVE GASSES AND WORKING IN THE VICINITY OF A BATTERY IS DANGEROUS. SOME BATTERIES GENERATE EXPLOSIVE GASES DURING NORMAL BATTERY OPERATION. FOR THIS REASON, IT IS OF UTMOST IMPORTANCE THAT EACH TIME BEFORE USING THIS UNIT, YOU READ THIS MANUAL AND FOLLOW THE INSTRUCTIONS EXACTLY.

To reduce risk of battery explosion, follow these instructions and those published by the battery manufacturer and manufacturer of any equipment you intend to use in the vicinity of the battery.

Review cautionary marking on all products.

PERSONAL PRECAUTIONS:

- Someone should be within range of your voice or close enough to come to your aid when you work near a battery.
- Have plenty of fresh water and soap nearby in case the battery electrolyte contacts skin, clothing, or eyes.
- Wear complete eye protection and clothing protection. Avoid touching eyes while working near a battery.
- If the battery electrolyte contacts skin or clothing, wash immediately with soap and water. If the electrolyte enters the eye, immediately flood the eye with running cold water for at least ten (10) minutes and get medical attention immediately.

INSTALLATION & OPERATING INSTRUCTIONS FOR PPC POWERPLUS

- Never smoke or allow a spark or flame in vicinity of a battery.
- Be extra cautious to reduce risk of dropping a metal tool onto a battery. It might spark or short-circuit the battery or other electric part that may cause an explosion.
- Remove personal metal items such as rings, bracelets, necklaces, and watches when working with a battery. A battery can produce a short-circuit current high enough to weld a ring or the like to metal, causing a severe burn.
- NEVER charge a frozen battery.

PREPARING TO CHARGE

- If necessary to remove the battery connections, always remove grounded terminal from the battery first. Make sure all loads are disconnected and unit is off, so as not to cause an arc.
- Be sure the area around the battery is well ventilated while the battery is being charged.
- When cleaning battery terminals, be careful to keep corrosion from coming in contact with eyes.
- Study all the battery manufacturer's specific precautions such as removing or not removing cell caps while charging, recommended rates of charge, and maintenance procedures.

UNIT LOCATION

- ◆ Never place this unit directly above the battery. Gases from the battery will corrode and damage equipment. A sealed maintenance free or valve regulated lead acid (VRLA) may be placed below this equipment.
- ◆ Never allow the battery electrolyte to drip on this unit when reading the specific gravity or filling the battery.
- ◆ Do not operate this unit in a closed-in area or restrict ventilation in any way.
- ◆ Do not set a battery on top of this unit.

D.C. CONNECTION PRECAUTIONS

Connect and disconnect d.c. output cables only after setting all of this unit's switches to off position and removing a.c. input supply.

GROUNDING INSTRUCTIONS

This battery charger should be connected to a grounded, metal, permanent wiring system; or an equipment grounding conductor should be run with circuit conductors and connected to equipment-grounding terminal or lead on battery charger. Connections to battery should comply with all local codes and ordinances.

CAUTION: DO NOT PULL ON OUTPUT CABLES WHEN DISCONNECTING CHARGER FROM BATTERY

RECEIVING INSTRUCTIONS AND GENERAL EQUIPMENT INFORMATION

CAUTION: To ensure safe installation and operation, the information given in the instruction manual should be read and understood before installing or using the equipment.

RECEIVING INSTRUCTIONS

Unpacking and Inspection: Examine the shipping crate upon arrival. If there is obvious damage, describe on the receiving documents. Within a few days after delivery, the equipment should be uncrated and carefully inspected for hidden damages. When removing packaging material, be careful not to discard any equipment, parts, or manuals. If any damage is detected you should:

1. File a claim with the carrier within five (5) days.
2. Send a copy of the claim to La Marche Mfg. Co.
3. Call La Marche Mfg. For a RETURN MATERIAL AUTHORIZATION NUMBER.

Failure to properly file a claim for shipping damages, or provide a copy of the claim to La Marche Mfg., may void warranty service for any physical damages reported for repair.

HANDLING

WARNING: Equipment can be very heavy, and top-heavy. Use adequate manpower or equipment for handling. Until the equipment is securely mounted, care must be used to prevent the equipment from being accidentally tipped over.

NOMENCLATURE PLATES

Each piece of La Marche Mfg. Equipment shipped is identified by part number on the nomenclature plate.

ADJUSTMENTS

All equipment is shipped from the factory fully checked and adjusted. Do not make any adjustments unless the equipment has been powered-up and the settings have been determined to be incorrect.

SPARE PARTS

To minimize downtime during installation or normal service, it is advisable to purchase spare fuses, circuit boards and other recommended components. Please refer to the list of recommended spare parts and their La Marche Mfg. Part numbers included with the instruction manual. It is recommended that spare fuses be ordered for all systems.

To order spare parts, please contact La Marche Mfg. (847)-299-1188 during business hours and ask for the Parts Department.

INSTALLATION & OPERATING INSTRUCTIONS FOR PPC POWERPLUS

INSTALLATION AND OPERATING INSTRUCTIONS FOR THE LaMARCHE PPC BATTERY CHARGER®

The PPC Battery Charger is designed to operate on a specific number of cells. The nameplate on the charger indicates the type and number of cells required. Once properly installed and adjusted, the charger should maintain the battery in a fully charged condition. Install the charger so that the flow of air through the ventilators is not obstructed. Binding posts with wire lug connectors or terminal blocks are provided within the unit. To "power up" the charger, use a.c. circuit breakers located on the door.

To operate the charger, connect the a.c. power to the terminals marked "A.C. INPUT". Connect the battery to the terminals marked "D.C. OUTPUT". Before connected the a.c. power, loads, or battery leads, observe the proper polarity, and be sure that the battery type, number of cells and the a.c. input voltage agree with information on the nameplate. To change a.c. input taps, see the label inside of the case or schematic. Make sure the d.c. breaker is in the "on" position before you "power up" the charger.

(NOTE: All 130Vdc units have a d.c. output fuse which replaces the breaker)

OPERATION

Upon installation, the desired float/equalize voltage may be obtained by adjusting the potentiometers. The float/equalize switch located on the door, must be in the proper position when setting the voltage. The charger will charge to its maximum rate and taper to a trickle charge when the battery reaches its float voltage. Check the battery manufacturers' specification for the proper float/equalize voltage settings and equalize cycle. For the lead batteries, see Chart 1 in this instruction.

AUTOMATIC CURRENT LIMITING

The PPC battery charger will charge to its maximum current capacity and begin to current limit if overloaded. The automatic current limiting feature limits the output of the charger to a maximum of 110% rated load.

ADJUSTMENTS

The unit is factory set at 2.25V/cell for float and 2.35V/cell for equalize (for lead battery) or 1.4V/cell for float and 1.55V/cell for equalize (nickel cadmium). (For different battery types, call the battery manufacturer.)

The charger is factory tested and preset. No field adjustments are necessary. However, the potentiometers and switches are provided for adjusting the float and equalize voltages to required levels. Should any further adjustments be necessary, *extreme care* should be taken. The voltmeter on the door will indicate the d.c. output voltage. The d.c. ampmeter will indicate the charging current.

Because of the stable, rugged, and static design of this unit, very little maintenance is required. Occasional blowing out of accumulated dust and tightening loose connections is the only maintenance required.

Note: The float/equalize voltage adjustment potentiometers are inside the unit. Right top corner, if ordered with the 16H option.

TROUBLESHOOTING

The unit should be returned to factory for repair. Call the factory (847)299-1188 for a Return Authorization Number (RMA).

INSTALLATION & OPERATING INSTRUCTIONS FOR PPC POWERPLUS

CHART #1

A.C. DRAW & FACTORY D.C.VOLTAGE SETTINGS:

<u>PPC MODEL LINE</u>	<u>120V</u>	<u>208V</u>	<u>240V</u>	<u>FLOAT</u>	<u>EQUALIZE</u>
PPC-6-12V-ABD1	1.00	0.60	0.50		
PPC-10-12V-ABD1	1.67	0.96	0.84	13.50	14.10
PPC-15-12V-ABD1	2.50	1.45	1.25		
PPC-6-24V-ABD1	2.00	1.15	1.00		
PPC-10-24V-ABD1	3.35	1.95	1.67	27.0	28.20
PPC-15-24V-ABD1	5.00	2.90	2.50		
PPC-6-48V-ABD1	4.00	2.30	2.00	54.00	56.40
PPC-10-48V-ABD1	6.70	3.85	3.35		
PPC-6-130V-ABD1	10.00	5.77	5.00	135.00	141.00

EQUALIZE AND FLOAT VOLTAGE PER CELL RANGES FOR:

NICAD BATTERIES

LEAD BATTERIES

	<u>MINIMUM</u>	<u>MAXIMUM</u>		<u>MINIMUM</u>	<u>MAXIMUM</u>
<u>EQUALIZE</u>	1.50	1.60	<u>EQUALIZE</u>	2.26	2.40
<u>FLOAT</u>	1.39	1.45	<u>FLOAT</u>	2.12	2.30

CHART #2

CASE SIZE AND WEIGHT:

<u>PPC MODEL LINE</u>	<u>H</u>	<u>W</u>	<u>D</u>	<u>LBS.</u>
PPC-6-12V-ABD1 PPC-10-12V-ABD1 PPC-15-12V-ABD1				
PPC-6-24V-ABD1 PPC-10-24V-ABD1 PPC-15-24V-ABD1	13.0	9.75	7.125	44.0
PPC-6-48V-ABD1				
PPC-10-48V-ABD1 ----- PPC-6-130V-ABD1	13.5	12.25	9.0	59.9

AGENCY APPROVALS: UL, cUL, FCC part 15 subpart B class A

INSTALLERS INFORMATION

The table below lists the a.c. and the d.c. minimum wire size requirements. At distances exceeding 10 feet, the d.c. wire size should be chosen to keep the voltage difference between the unit's terminals and the battery at less than 1/2 volt when the unit is fully loaded. If the distance between the unit and the battery exceeds 10 feet, use the Power Cabling Formulas to determine wire size.

WIRE SIZE TABLE
(Based upon unit fuse size)

FUSE SIZE	WIRE SIZE REQUIREMENT CUSTOMER CONNECTION	EQUIPMENT GROUNDING CONDUCTOR MINIMUM	FUSE SIZE	WIRE SIZE REQUIREMENT CUSTOMER CONNECTION	EQUIPMENT GROUNDING CONDUCTOR MINIMUM
1	#14	#14	150	#1	#6
3	#14	#14	175	#1/0	#6
4	#14	#14	200	#2/0	#6
5	#14	#14	225	#2/0	#4
6	#14	#14	250	#4/0	#4
10	#14	#14	300	250-MCM	#4
15	#12	#12	350	350-MCM	#2
20	#12	#12	400	400-MCM	#2
25	#10	#12	450	500-MCM	#2
30	#10	#10	500	600-MCM	#2
35	#8	#10	600	900-MCM	#1
40	#8	#10	700	1500-MCM	1/0
45	#8	#10	800	2/500-MCM	1/0
50	#8	#10	1000	2/800-MCM	4/0
60	#6	#10	1200	2/1000-MCM	4/0
70	#6	#8	1600	2/2000-MCM	4/0
80	#4	#8	2000		250-MCM
90	#4	#8	2500		350-MCM
100	#4	#8	3000		400-MCM
110	#2	#6	4000		500-MCM
125	#2	#6	5000		700-MCM
130	#2	#6	6000		800-MCM

NOTE: These are recommended wire sizes. All National and Local Wiring Codes must be followed.

POWER CABLING FORMULAS

WIRE GAUGE TABLE

SIZE AWG	AREA CIR. MILS	SIZE MCM*	AREA CIR. MILS
18	1620	250	250000
16	2580	300	300000
14	4110	350	350000
12	6530	400	400000
10	10380	500	500000
8	16510	600	600000
6	26240	700	700000
4	41740	750	750000
3	52620	800	800000
2	66360	900	900000
1	83690	1000	1000000
0	105600	1250	1250000
00	133100	1500	1500000
000	167800	1750	1750000
0000	211600	2000	2000000

*Denotes all sizes larger than #0000 are expressed in MCM.

TABLE OF CONVENTIONS:

- CMA = Cross-section of wire in circular MIL area.
- A = Ultimate drain in amperes.
- LF = Conductor loop feet.
- MAX AMP = Maximum allowable amperes for given voltage drop.
- CMA = Cross section of wire in circulate MIL area.
- AVD = Allowable voltage drop.
- LF = Conductor loop feet.
- K = 11.1 Constant factor for commercial (TW Type) copper wire (KS5482-01).
- = 17.4 for aluminum (KS20189)

1. Calculating Wire Size Requirements..... $CMA = \frac{A \times LF \times K}{AVD}$

2. Calculating Current Carrying Capacity of Wire..... $Max\ Amp = \frac{CMA \times AVD}{LF \times K}$

SOURCE: HANDBOOK 100-NATIONAL BUREAU OF STANDARDS

NOTE: ALL WIRE #6 AND LARGER IS STRANDED.

MANUFACTURER'S WARRANTY

All La Marche Manufacturing Co. equipment has been thoroughly tested and found to be in proper operating condition upon shipment from the factory and is warranted to be free from any defect in workmanship and material that may develop within one year from date of purchase. In addition to the standard one (1) year warranty, La Marche warrants its magnetics and power diodes on a parts replacement basis only for four (4) more years under normal use.

Any part or parts of the equipment (except fuses, d.c. connectors and other wear-related items) that prove defective within a one (1) year period shall be replaced without charge providing such defect, in our opinion, is due to faulty material or workmanship and not caused by tampering, abuse, misapplication or improper installation. Magnetics and power diodes are warranted for five (5) years after date of purchase. During the last four (4) years of this five (5) year warranty period, the warranty covers parts replacement only, and no labor or other services are provided by La Marche, nor is La Marche obligated to reimburse the owner or any other person for work performed.

Should a piece of equipment require major component replacement or repair during the first year of the warranty period, these can be handled in one of two ways:

1. The equipment can be returned to the La Marche factory to have the inspections, parts replacements and testing performed by factory personnel. Should it be necessary to return a piece of equipment or parts to the factory, the customer or sales representative must obtain authorization from the factory. If upon inspection at the factory, the defect was due to faulty material or workmanship, all repairs will be made at no cost to the customer during the first year. Transportation charges or duties shall be borne by purchaser.
2. If the purchaser elects not to return the equipment to the factory and wishes a factory service representative to make adjustments and/or repairs at the equipment location, La Marche's field service labor rates will apply. A purchase order to cover the labor and transportation cost is required prior to the deployment of the service representative.

In accepting delivery of the equipment, the purchaser assumes full responsibility for proper installation, installation adjustments and service arrangements. Should minor adjustments be required, the local La Marche sales representative should be contacted to provide this service only.

All sales are final. Only standard LaMarche units will be considered for return. A 25% restocking fee is charged when return is factory authorized. Special units are not returnable.

In no event shall La Marche Manufacturing Co. have any liability for consequential damages, or loss, damage or expense directly or indirectly arising from the use of the products, or any inability to use them either separately or in combination with other equipment or materials, or from any other cause. In addition, any alterations of equipment made by anyone other than La Marche Manufacturing Co. renders this warranty null and void.

La Marche Manufacturing Co. reserves the right to make revisions in current production of equipment, and assumes no obligation to incorporate these revisions in earlier models.

The failure of La Marche Manufacturing Co. to object to provisions contained in customers' purchase orders or other communications shall not be deemed a waiver of the terms or conditions hereof, nor acceptance of such provisions.

The above warranty is exclusive, supersedes and is in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness. No person, agent or dealer is authorized to give any warranties on behalf of the Manufacturer, nor to assume for the Manufacturer any other liability in connection with any of its products unless made in writing and signed by an official of the manufacturer.